

# HP Pavilion 14-b120dx Audio Port/USB Drive Replacement

This guide will walk you through replacing the...

Written By: Erin Lavalla



#### INTRODUCTION

This guide will walk you through replacing the audio port and USB drive card using an iFixit PH0 screwdriver and plastic opening tool.

#### TOOLS:

Phillips #0 Screwdriver (1) iFixit Opening Tool (1)

#### Step 1 — Battery



⚠ Power down the laptop and detach the charging cord (failure to do so can result in electrical shock).







- Flip the laptop upside down so that the bottom is facing you.
- Push the slide on the right toward the center of the laptop, releasing the battery latch.
- Lift the battery up and away from the laptop.

#### Step 3 — Keyboard









- Insert the plastic opening tool between the keyboard and the palm rest.
- Pry upwards until the keyboard section detaches from the laptop.
- Repeat this around the edge of the entire keyboard.
- (i) Sections will make loud snapping noises as they detach from the palm rest this is normal.






- Lift the keyboard slowly up until the connecting cable is exposed.
- Carefully lift the flap on the ZIF connector using a fingernail or plastic opening tool. This will release the cable.
- Detach the cable.

#### Step 5 — Palm Rest





 Unscrew the 10 6.0 mm screws under the keyboard housing with a Philips #0 head screwdriver.








- Insert the plastic opening tool into the seam between the palm rest and the laptop.
- Pry upwards until the palm rest separates from the laptop.
- Repeat this process around the entire computer.
- (i) These steps will be similar to the ones you took to remove the keyboard. Again, you will hear snapping noises.

## Step 7




Lift upwards to remove the palm rest.

## Step 8 — Audio Port and USB drive



• Carefully disconnect the cable connecting the ports to the motherboard from the right side.

## Step 9



Remove the two 6.0 mm screws from the ports.





Push the ports to the left and lift upward to remove them safely.

To reassemble your device, follow these instructions in reverse order.