



Toshiba Satellite L775D-S7340 Battery Replacement

This guide will show you how to remove and...

Written By: Elizabeth Sadewasser



INTRODUCTION

This guide will show you how to remove and replace the battery.

Step 1 — Battery



- Make sure the laptop is unplugged and powered off.
- Locate the battery latches on the underside of the laptop.

Step 2



- Slide the right latch to the right until you hear it lock into place.
- Slide the left latch to the left and hold it.

Step 3



- Slide the battery out towards you.

To reassemble your device, follow these instructions in reverse order.

