



Logitech Harmony 900 Battery Replacement

This guide will teach you how to remove the Logitech Harmony 900 battery

Written By: Tyler Hanks



INTRODUCTION

This guide will teach you how to remove the Logitech Harmony 900 battery.

Step 1 — Battery



- Press the oval shaped button on the lower back of the remote to release the battery cover.
- While pressing the button, remove the cover.

Step 2



- Push the battery in, pull it up, and slide it out.

To reassemble your device, follow these instructions in reverse order.