

# **Dell Vostro 1440 KeyBoard Replacement**

Written By: Johnathan Hammond





Spudger (1)

## Step 1 — Battery





- Slide the release latches to unlock the battery.
  - Slide the battery and remove it from the computer.

## Step 2 — KeyBoard



 Pry up to release the top four snaps securing the keyboard to the computer.

## Step 3



• Flip the keyboard over and lay it on the palm rest.

### Step 4



• Disconnect the keyboard cable from the system board.

## Step 5



Remove the keyboard from the computer.

To reassemble your device, follow these instructions in reverse order.