

## **Dell Vostro 1014 Hard Drive Replacement**

Written By: Johnathan Hammond





Phillips #0 Screwdriver (1)

## Step 1 — Battery





- Slide the battery latches apart to the unlock position.
  - Lift the battery from the computer.

## Step 2 — Access Panel





- Remove the six screws that secure the access panel to the computer.
  - Remove the access panel from the computer.

## Step 3 — Hard Drive





- Remove the four screws that secure the hard drive assembly to the computer.
  - Pull the mylar tab towards the hard drive assembly to release the hard drive interposer from the connector on the system board.
  - Lift the hard drive assembly from the computer.

To reassemble your device, follow these instructions in reverse order.