

# iPad 3 Wi-Fi Headphone Jack Cable Replacement

Internal prereq.

Written By: Walter Galan



This document was generated on 2020-11-13 06:46:58 PM (MST).

## **INTRODUCTION**

Internal prereq.



## TOOLS:

• Spudger (1)

#### Step 1 — Headphone Jack Cable







- Peel back and remove the piece of electrical tape covering the headphone jack assembly cable connector.
- Using the tip of a spudger, flip up the retaining flap on both of the ZIF connectors securing the headphone jack cable to the logic board.

### Step 2





- Slide the flat end of a spudger underneath the headphone jack assembly cable, releasing the adhesive securing it to the rear aluminum frame.
- Pull the headphone jack assembly cable straight out of its socket on the logic board.

To reassemble your device, follow these instructions in reverse order.