



Samsung Galaxy Amp 2 Screen Replacement

Repair your broken or damaged screen with this...

Written By: Cory Nickolatos



INTRODUCTION

Repair your broken or damaged screen with this guide. A replacement may be needed if the screen is cracked or unresponsive. This guide recommends use of a heat gun, though a blow dryer can be used instead. Use care when applying heat to the screen and carefully detach delicate wiring to avoid damaging the phone.

TOOLS:

[Tweezers - Pro ESD Angle](#) (1)
[Suction Handle](#) (1)
[iFixit Opening Tool](#) (1)
[Heat Gun](#) (1)

PARTS:

[Galaxy Amp 2 screen](#) (1)

Step 1 — Battery



- Insert your fingernail or an opening tool into the divot on the side of the phone. The divot is located to the left of the rear-facing camera.
- Lift upwards and gently pry the rear panel off of the phone.

Step 2



- Insert a fingernail or plastic opening tool into the gap in the bottom right corner of the battery and lift upward.
- Grip the battery and safely remove it from the phone.

Step 3 — Screen




- Using angled [tweezers](#), lift the small rectangular guard at upper right corner of the phone.
- Disconnect the connector piece from the back panel.

Step 4



- Apply heat from heat gun or blow dryer on periphery of the screen for one to two minutes.

Step 5



- Use four plastic opening tools to gently pry off the screen.

ⓘ *Optional:* Use a suction tool to pull the screen off.

To reassemble your device, follow these instructions in reverse order.