



Hoover Lander (LA71_LA30011) Motor filter Replacement

How to replace the main motor filter without buy a new one.

Written By: Carlo Romagnoli



 **TOOLS:**

- [Cutter](#) (1)
- [Phillips #0 Screwdriver](#) (1)

 **PARTS:**

- [Foam](#) (1)
- Foam
- [Metal grid](#) (1)
 - [medical gauze](#) (1)

Step 1 — The Hoover



- 700 w cyclonic hoover

Step 2 — The filter (broken one)



- The active carbon filter is totally **blocked**. Air cannot flow !!!

Step 3 — Remove the carbon filter



- Using a *screwdriver* and a *cutter* is almost simple to remove the filter.

Step 4 — Goods to replace the filter



- Metal grid
- Foam
- Gauze

Step 5 — Building the new filter



- Cut the metal grid and place it.
- Place the gauze (just a couple of sheets) over the grid.
- Cut and place the foam on top of the gauze.

Step 6 — The - new - Filter



- Insert wisdom here.

Step 7 — Reassemble



- Insert wisdom here.

To reassemble your device, follow these instructions in reverse order.