

# iMac G5 20" Model A1145 Access Door Replacement

Written By: Andrew Bookholt



## **INTRODUCTION**

Remove the access door to replace RAM chips.



# TOOLS:

Phillips #1 Screwdriver (1)

#### Step 1 — Access Door



- Orient the iMac face-side down on a table with the bottom edge facing yourself.
- Remove the two Phillips screws securing the access door to the bottom grille of your iMac.
- The screws are captive in the access door.
- ⚠ Before beginning the repair, unplug the computer and press and hold the power switch for 20-30 seconds, to discharge internal capacitors.

### Step 2



Remove the access door.

To reassemble your device, follow these instructions in reverse order.