



Ion Air Pro Power Button Replacement

This guide provides instruction on how to replace the Power Button.

Written By: Christopher Brandl



INTRODUCTION

Is your camera not turning on or turning off? Consider using this guide to replace the power button of your device.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Power Button



- Remove the 6 screws that secure the lens cover bezel with a #00 Phillips screwdriver.

Step 2



- Slide off the black aluminum casing.

Step 3



- Unscrew the top screw that is by the power button using a #00 Phillips screwdriver.

⚠ A spring is being held down by the screw. be sure to hold it down.

Step 4



- Lift off the plastic part holding the power button in place.

Step 5



- Remove the power button from the device.

To reassemble your device, follow these instructions in reverse order.