



Toshiba Tecra M11 Battery Replacement

This guide will accomplish the steps in order to replace the battery.

Written By: Jessica Jaramillo



INTRODUCTION

If your Toshiba Tecra no longer turns on the the battery doesn't last long, this guide gives you the steps to change the battery.



TOOLS:

- [Fingers](#) (1)
-

Step 1 — Battery



- Unlock the battery by sliding both tabs at the same time.

Step 2



- After, you unlock both sides of the battery, gently slide the battery off by pulling towards yourself.

To reassemble your device, follow these instructions in reverse order.