

Kyocera DuraForce Pro Battery Replacement

Learn how to remove and replace the battery of a Kyocera DuraForce Pro.

Written By: Dylan Ulbricht





- JIS #0 Screwdriver (1)
- Tweezers (1)
- iFixit Opening Tools (1)

Step 1 — Battery







- Be sure the device is turned off.
- Flip the phone onto its backside.
- Remove the back cover by using a plastic opening tool.

Step 2







Remove the eight screws with a JIS #0 screwdriver.

Step 3







Once the back cover is removed, the (6) buttons along the side are going to fall out of place.

Step 4







- Using the plastic opening tool from earlier, lift the battery out by wedging it along the edge.
- Using tweezers, unlock the ribbon cable port and lightly pull the cable upwards until it becomes unplugged.

To reassemble your device, follow these instructions in reverse order.