



# Samsung SGH A707 Motherboard Replacement

This guide will demonstrate how to replace your...

Written By: yfm



## INTRODUCTION

This guide will demonstrate how to replace your Samsung SGH A707 phone's motherboard. Over time or as a result of physical damage, the Samsung SGH A707 motherboard may need to be replaced. One sign your motherboard needs replacing is unresponsive keys.

---

### TOOLS:

[Tweezers](#) (1)

[Phillips #0 Screwdriver](#) (1)

[iFixit Opening Tool](#) (1)

---

## Step 1 — Battery



- Press on the markings on the cover and pull it down to reveal the battery.

## Step 2



- Use your fingers to pull the battery out of its position. You may also flip the phone and the battery will fall out.

## Step 3



- Here is the phone without the battery.

## Step 4 — Motherboard



- Unscrew the six screws on the back of the phone using the Phillips #0 screw driver.

## Step 5



- Use the prying tool the pry off the phone's plastic frame.

## Step 6



- Use the prying tool to disconnect the rectangular connector.

## Step 7



- Use the prying tool to disconnect the small connector.

## Step 8



- Gently pull off the circuit board.

## Step 9



- Here is the phone without the logic board.

---

To reassemble your device, follow these instructions in reverse order.