



Panasonic KX-TG6641 Battery Replacement

Replace batteries in a Panasonic KX-TG6641 handset.

Written By: Kevin Hain



INTRODUCTION

Use this guide to correctly replace the batteries in one of the handsets in your Panasonic phone. Replacing the battery will improve the overall usability of the phone and will result in all features of the phone operating properly.

This procedure applies to all handsets that are given with the device.



PARTS:

- [AAA Battery](#) (2)

Common item. Can be purchased in most stores.

Step 1 — Battery



- Remove the battery cover by sliding the cover piece down

Step 2



- Remove the two AAA batteries.

To reassemble your device, follow these instructions in reverse order.