



ZTE Whirl 2 Battery Replacement

How to replace the battery in the ZTE Whirl 2.

Written By: Alana Rucks



INTRODUCTION

Use this guide if you need to remove or replace your battery for ZTE Whirl 2 Model Z776G. Before you start refer to the [Troubleshooting Page](#) to see if there is another solution to your problem.

Step 1 — Battery



- Power off your phone before removing the battery.
- Pry the cover off the back of the phone using your fingers.

Step 2



- Pry the battery from the phone using your fingers.

To reassemble your device, follow these instructions in reverse order.