



Dell Latitude E6530 Battery Replacement

This guide will walk users through the process of replacing a battery on the Dell Latitude E6530.

Written By: Amelia Jochem



INTRODUCTION

This guide will take users through replacing the Dell Latitude E6530 battery. Refer to the troubleshooting page before beginning to be sure the battery needs replacement.

Step 1 — Battery



- Flip the computer over so that the bottom panel is facing you.

Step 2



- Slide the switches away from each other to release the battery.

Step 3



- Using your hands, gently remove the battery from the device.

To reassemble your device, follow these instructions in reverse order. If issues arise after replacing the battery, refer to the troubleshooting page or additional links for more help.