Dell Latitude E6230 12.5" HD (1366x768) Anti-Glare WLED-backlit Replacement

Replacement of Dell Latitude E6230 12.5" HD laptop screen

Written By: alarson118



This document was generated on 2021-03-21 07:10:53 AM (MST).

TOOLS:

- Phillips #1 Screwdriver (1)
- iFixit Opening Tools (1)

PARTS:

- 12.5" HD (1366x768) Anti-Glare WLED-backlit (1)

© iFixit — CC BY-NC-SA

Step 1 — Remove Battery





- Slide the release latches to unlock the battery.
- Remove the battery from the computer.

Step 2 — Removing the Display Bezel







- Pry the top edge of the display bezel.
- Work your way along to the sides and bottom edge of the display bezel
- Remove the display bezel from the display assembly

© iFixit — CC BY-NC-SA

Step 3 — Removing the Display Panel







- Remove the 6 (M2 x 3mm) screws that secure the display panel to the display assembly
- Flip the display panel over
- Peel off the LVDS cable connector tape and disconnect the LVDS cable from the display panel
- Remove the display panel from the display assembly

To reassemble your device, follow these instructions in reverse order.

© iFixit — CC BY-NC-SA