

How to Replace a G-Shock GA201-1A Battery

Use this guide to replace the battery for your...

Written By: Cordell Johnson



INTRODUCTION

Use this guide to replace the battery for your Casio G-Shock GA201-1A watch.

G-Shock watches are popular watches designed to resist stress, shock, water, and vibration. The lithium battery needed for this watch replacement is long-lasting, depending on the usage for the watch. Typically, the lithium battery provided in G-Shock watches lasts two to six years. The lifespan depends on how often you use the alarm or the backlight features. Frequently using either will drain the battery pretty fast and cause the need for replacement.

This guide is needed for all G-Shock owners because maintaining our watches improves the quality and experience. This brand of watches is long-lasting and durable, but it's essential to know how to take care of it in the event of overuse.

This guide will show a detailed and easy process to carefully replace the battery for this particular model. This is a user-friendly and straightforward process that anyone can accomplish to restore their watch.

Once you have completed the guide, your watch will reset. Be sure to check out the <u>G-Shock</u> <u>GA201-1A user manual</u> to properly set to the correct timezone and date.

₹ TOOLS:

Tweezers (1)
Phillips #0 Screwdriver (1)

PARTS:

Casio G-Shock GA201-1A (1) CR 1220 Battery (1)

Step 1 — Battery







- Remove back cover by removing the four 6.2 mm Phillips #0 screws with the screwdriver.
- Be careful not to lose the screws.



 Use the tweezers to remove the rubber gasket by lifting it.

Step 3



• Lift the white plastic covering with a pair of tweezers.

⚠ Be delicate; if too much force is applied, the watch's interior can pop out.



 Peel off the protective sticker from the surface of the old battery.

Step 5



 Use tweezers to bend the metal guide away from the old battery.



 Remove the old battery from the guide with tweezers.

Step 7



• Slide the new battery into the frame and bend the metal guide onto the battery.



- Reset the proper time and date using the top-left "adjust" button.
- i For further instructions, consult your G-Shock GA-201 User Manual.

To reassemble your watch, follow these instructions in reverse order.

For optimal performance, after completing this guide, <u>calibrate</u> your newly installed battery.

Take your e-waste to an R2 or e-Stewards certified recycler.