



Repairing Polaroid Sun 600 LMS Gear Train

Written By: Matthew Lessig



INTRODUCTION

How to manually advance a stuck gear train.

TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — Open film door



- Move film door slide on the left side of camera forward.
- Pull film door open.

Step 2



- Locate small silver gear in top left corner of film bay.

Step 3



- Using a plastic opening tool, rotate gear downward until jam is cleared.

To reassemble your device, follow these instructions in reverse order.