



Fairphone 1 Back Cover Replacement

Replace the Back Cover in your Fairphone.

Written By: Andrew Optimus Goldheart




INTRODUCTION

Use this guide to replace a dented, or otherwise damaged, back cover on your Fairphone.

Step 1 — Back Cover



 There is a small indentation in the side of the phone near the bottom of the back cover.

- With the indentation as leverage, use your fingernail to pry the bottom portion of the back cover from the phone.

Step 2



- Slide the back cover down and remove it from the phone.

To reassemble your device, follow these instructions in reverse order.