



# Focusing the Camera

How to use the shutter button on your PowerShot A4000 camera to insure your shots are in focus.

Written By: Ansley Gardner



## Step 1 — How to Focus the Camera



- The shutter button is highlighted in red. To focus your camera, press this button down halfway.
  - Your camera will beep twice and a frame will appear around the object on your display screen that is being brought into focus.
  - Once this frame appears on the display screen, press the shutter button all the way down, taking the picture.
- ⚠ The camera will make a shutter sound. Make sure to hold the camera very still until this sound ends.

To reassemble your device, follow these instructions in reverse order.