

Xbox 360 Faceplate Replacement

Written By: Walter Galan



INTRODUCTION

This guide is an internal guide used as a prereq.



TOOLS:

• Spudger (1)

Step 1 — Faceplate





- Insert the flat edge of a spudger between the faceplate and the outer casing near the power button.
- Run your spudger along the edge of the faceplate to release the clips securing it to the front of the console.
- You may also accomplish this task by using the edge of the Xbox 360 opening tool, but it may scratch the plastic case.
- (i) Alternatively, you can use your hands to carefully pull the faceplate away from the Xbox.

Step 2



 Repeat the same motions as previously mentioned to release the left side of the faceplate.

Step 3



 Remove the faceplate from the front face of the console.

To reassemble your device, follow these instructions in reverse order.