



iPad Mini 3 Wi-Fi Front Facing Camera Cable Replacement

Prereq only.

Written By: Sam Goldheart



INTRODUCTION

Prereq only.

TOOLS:

[Tweezers](#) (1)
[iFixit Opening Tool](#) (1)

Step 1 — Front Facing Camera Cable



- Use a set of [tweezers](#) to remove any tape covering the front-facing camera cable clips.

Step 2



- Use a plastic opening tool to fold the front-facing camera cable clips outward, away from the cable, freeing the cable connector.

Step 3



- Use a plastic opening tool to lift the front-facing camera cable connector straight up off of its socket on the logic board.

⚠ Be sure to only pry on the connector, **not** the socket itself.

To reassemble your device, follow these instructions in reverse order.