



# Samsung WB150F Battery Replacement

This guide will provide steps on how to replace the battery in a Samsung WB150F.

Written By: Joshua Paul Leite



## INTRODUCTION

Sometimes the battery is dead or needs to be replaced with a new one. Follow the steps below to answer any questions you may have about replacing the battery.

## Step 1 — Battery



- The location of the battery compartment can be found on the underside of the camera.

## Step 2



- Have the lens of the camera face you. To open the battery compartment, slide the battery door lock towards the left. At the same time allow the battery door to swing open.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2022-04-28 12:43:25 PM (MST).

