Toshiba Satellite C55D-A5201 RAM Replacement

This guide will show you how to remove the RAM module from the Toshiba Satellite C55D-A5201.

Written By: Ashley Cannon

This document was generated on 2020-11-28 04:27:13 AM (MST).

www.iFixit.com

INTRODUCTION

Remove the RAM module with this guide. Reverse the steps to install a new one to allow for more laptop storage.

🔧 TOOLS:

- Phillips #00 Screwdriver (1)

Step 1 — Battery

- Close the laptop, and flip it upside down. You want the spine to be furthest away from you.

Step 2

- Release the locking mechanism by switching the left slider to the left.

Step 3

- Slide the right slider to the right, and simultaneously, pull the battery out at a diagonal angle.

Step 4 — RAM

- With the Phillips #0 screwdriver, unscrew the 4.6mm screw on the left side of the "L"-shaped covering.

This document was generated on 2020-11-28 04:27:13 AM (MST).

Step 5

- Lift up the "L"-shaped plastic covering to remove it.

Step 6

- Push the two metal prongs on either side of the RAM module away from the module simultaneously.

- Lift up the RAM module to remove.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-28 04:27:13 AM (MST).