



Sharp Aquos LC13B2UA Stand Replacement

This is a simple solution for replacing a...

Written By: Robert Hobson



INTRODUCTION

This is a simple solution for replacing a broken or malfunctioning stand for the Sharp Aquos LC13B2UA TV. This repair uses screws instead of glue to attach the replacement stand for a solid hold.

Before beginning these instructions, clear the area of any liquids, turn the TV off, and unplug the power cord from the AC outlet. Be sure that the replacement part is identical to the original part.



TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Stand



- Place the TV face down on a flat smooth surface as to not scratch the screen.
- Using a Phillips #2 screwdriver remove the four 8mm screws attaching the stand to the TV.

Step 2



- Lift the stand off the television.

To reassemble your device, follow these instructions in reverse order.