

Nintendo Wii U Pro Controller Teardown

Travel into the Controller.

Written By: Frederic Morelli





- Phillips #000 Screwdriver (1)
- Spudger (1)

Step 1 — Back panel.







With the PH000 screwdriver get back the rear front.

Step 2 — Battery off.







- Get back the battery with a tool like a spudger.
- i The battery is not stucked.