


# Zoomer Dino Boomer Main Circuit Board Replacement

This guide shows how to safely separate the...

Written By: Desiree DesJardins



#### **INTRODUCTION**


This guide shows how to safely separate the main circuit board from the remainder of Zoomer Dino Boomer so that it can be replaced without damage to the electrical system.



## TOOLS:

- Phillips #1 Screwdriver (1)
- Spudger (1)
- Tweezers (1)
- Phillips #0 Screwdriver (1)
- Lead-Free Solder (1)
- Soldering Workstation (1)

#### Step 1 — Back Cover



- Power off Zoomer Dino Boomer before disassembly.
- Remove the eight 9.3mm Phillips #1 screws.

## Step 2







- Turn dinosaur over and hold upright.
- Use the spudger to pry apart the back cover from the remainder of the Zoomer Dino Boomer.
- A Be gentle while removing the back cover. The back cover of the Zoomer Dino Boomer is still connected to the electronic system by a wire.

This document was generated on 2022-12-30 03:58:12 PM (MST).

#### Step 3










- Disconnect the wire that connects the back cover of the dino to the main circuit board by carefully pulling on the orange wire connector with tweezers.
- Remove back cover.
- (i) If you are having difficulty removing the connector from its socket, push in the small tabs on the side of the connector with the tweezers. This step may take some work.
- No not damage the wires or circuit board.

#### Step 4 — Main Circuit Board







• Use tweezers to remove all of the colored wire connectors from their sockets on the circuit board.


# Step 5






Remove legs.


# Step 6




 Remove the three 7.2 mm Phillips #0 screws connecting the main circuit board to the body of Zoomer Dino Boomer.

### Step 7







- Use soldering iron and tweezers to disconnect main circuit board from the black and red wires.
- Check out iFixit's <u>soldering techniques guide</u> to learn more about soldering and desoldering connections.
- Remove main circuit board from Zoomer Dino Boomer

To reassemble your device, follow these instructions in reverse order.