



Dell XPS 17 L702X Battery Replacement

A guide to replace battery for the Dell XPS 17 L702X

Written By: Shin Sul



INTRODUCTION

This guide shows how to remove and replace the battery for the Dell XPS 17 L702X laptop.



PARTS:

- [Dell XPS 14, XPS 17 3D, and XPS L701x 3D Replacement Battery](#) (1)
-

Step 1 — Battery



- ❗ Before you begin, be sure to turn off your laptop and unplug it from the outlet.
- Flip over the laptop so that the bottom battery compartment faces upwards.

Step 2



- Slide the tab below the battery to the left and hold the tab in place.

Step 3



- While holding the tab, lift the battery out of its compartment.
- Release the tab after removing the battery.

For optimal performance, after completing this guide, [calibrate](#) your newly installed battery.

Take your e-waste to an [R2 or e-Stewards certified recycler](#).