

Dell Inspiron 5100 PP07L Hard Drive Replacement

If you want to replace your hard drive for a larger drive or if it's corrupted.

Written By: May Chauvin



This document was generated on 2020-11-28 03:37:49 AM (MST).

INTRODUCTION

You will learn how to remove the hard drive.



TOOLS:

• Phillips #1 Screwdriver (1)



PARTS:

- 1 TB SSD / Upgrade Bundle (1)
- 250 GB SSD / Upgrade Bundle (1)
- 500 GB SSD / Upgrade Bundle (1)
- 2 TB SSD (1)

Step 1 — Hard Drive



 With the lid closed, place the laptop upside-down on a flat surface.

Step 2





- Remove the two 5.8mm screws securing the hard drive bay.
 - If the computer was right-side-up and rotated for use, the bay would be found in the rear left corner.

Step 3



 Grasp the plastic bay handle and slide outwards to remove.

To reassemble your device, follow these instructions in reverse order.