



Fujifilm FinePix S1 Battery Replacement

Replace your battery to get your camera to turn on.

Written By: Brandon Benavente



INTRODUCTION

Following this guide will involve the very easy changing of the battery for your camera.

Step 1 — Battery



- Release the slide on the battery cover and open the hatch.

 Make sure camera power is OFF.

Step 2



- Pull back on the orange battery release clip and allow the battery to pop up.

Step 3



- Remove the battery from the camera.

To reassemble your device, follow these instructions in reverse order.