



Nikon N2000 (F301) Lens Mount Replacement

How to remove the lens mount from the camera.

Written By: Zachary Phillips



INTRODUCTION

If you are having trouble mounting the lens and you are sure you have the correct lens type (see the [camera manual](#) for types of lenses that can be used), then use this guide to assist with replacing the lens mount.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)

Step 1 — Lens Mount



- Use a 00 Phillips head screwdriver to remove the four screws from the lens mount.

Step 2



- Remove lens mount from the camera.
- ⚠ Be careful not to lose any of the three loose pieces that are under the lens mount.

To reassemble your device, follow these instructions in reverse order.