



MacBook Air 11" Mid 2011 Lower Case Replacement

Replace the lower case on your MacBook Air 11" Mid 2011.

Written By: Walter Galan



INTRODUCTION

Use this guide to remove the lower case.



TOOLS:

- [P5 Pentalobe Screwdriver Retina MacBook Pro and Air](#) (1)



PARTS:

- [MacBook Air 11" \(Late 2010-Mid 2011\) Lower Case](#) (1)
- [MacBook Air Rubber Feet](#) (1)

Step 1 — Lower Case



- ❗ Shut down and close your computer. Lay it on a soft surface top-side down.
- Remove the following ten screws:
 - Two 8 mm 5-point Pentalobe screws
 - Eight 2.5 mm 5-point Pentalobe screws
- ❗ The special screwdriver needed to remove the 5-point Pentalobe screws can be found [here](#).

Step 2



- Wedge your fingers between the display and the lower case and pull upward to pop the lower case off the Air.

To reassemble your device, follow these instructions in reverse order.