



# HP Pavilion 14-c015dx Chromebook Battery Replacement

This guide will help you remove and replace your battery for the laptop.

Written By: Alexandra Garro



## INTRODUCTION

This guide will walk you through the steps to remove and replace the battery. This is a very easy fix because the battery is on the outside of the laptop and simple to remove: There are no other components blocking your access to battery. Here is a link to buy a replacement battery: [Dr. Power Battery](#)

## Step 1 — Battery



- Set the lock switch to the orange unlocked position.

## Step 2



- Slide the right side switch to the left so the battery sign does not show.
- Once this switch is pushed, the battery will pop out slightly and you can pull the battery out completely.

To reassemble your device, follow these instructions in reverse order.