



Kenwood KDC-BT565U Face Plate Replacement

This guide will walk you through the process of replacing the face plate in a Kenwood KDC-BT565U.

Written By: Darren Evans



INTRODUCTION

The face plate in a Kenwood KDC-BT565U can be removed to either keep separate from a vehicle, perform a hard reset, or to repair/replace a component. This guide will show you how to replace the face plate.



PARTS:

- [Kenwood KDC-BT565U Replacement Faceplate](#) (1)
-

Step 1 — Face Plate



- Press the eject button on the bottom left corner of the face plate.

Step 2



- Begin by slightly lifting the face plate out from the side located by the release button.
- Slide towards the side of the eject button, *then* completely lift out.

To reassemble or replace, follow the steps in reverse order with the working faceplate.