



Motorola C168 Battery Replacement

Written By: Christopher Wu



⚙️ PARTS:

Motorola C168 Replacement Battery (1)

Step 1 — Battery



- Turn the phone so its back is facing you.
- Press the release button on the back cover, while simultaneously pulling the cover down.
- Remove the back cover.

Step 2



- Pinch the sides of the bottom of the battery and pull upward.

To reassemble your device, follow these instructions in reverse order.