

Samsung SmartCam HD Mount Replacement

This guide will walk you through the steps of how to remove your mount on the Samsung SmartCam.

Written By: Christopher Michael Tartaglia



INTRODUCTION

This guide will walk you through the steps of how to remove your mount on the Samsung SmartCam.

Step 1 — Mount







Rotate the mount counter-clockwise, 7-8 times or until the clip is loose.

Step 2





Separate the mount from the camera and set the mount aside.

To reassemble your device, follow these instructions in reverse order.