



# Xbox 360 Wireless Controller Front Case Replacement

Cracked controller case? Tired of a solid...

Written By: Brett Hartt



# INTRODUCTION

Cracked controller case? Tired of a solid color? Bring new life to your Xbox 360 controller with a new front case.

## TOOLS:

[Spudger](#) (1)  
[T8 Torx Security Bit Screwdriver](#) (1)  
[Tweezers](#) (1)

## PARTS:

[Xbox 360 Wireless Controller Front Panel \(Transforming D-Pad\)](#) (1)

## Step 1 — Battery



- Depress the battery release button on the top of the controller.
  - Remove the battery holder from the controller.
-  The standard option for Xbox 360 Wireless Controllers Battery Packs is AA batteries. A rechargeable battery is also available, but both battery options are removed from the controller in the same way.

## Step 2 — Rear Case



- Use a pair of [tweezers](#) to peel the barcode sticker from the battery compartment.

## Step 3



- Remove the seven 9.3 mm T8 Security Torx screws securing the rear case to the front case.

## Step 4



- Insert a [Spudger](#) between the front and rear cases along the left edge of the controller.
- Rotate the spudger toward the front of the controller, prying the two cases apart.

## Step 5



- Insert a spudger between the front and rear cases, near the headphone jack.
- Rotate the spudger toward the front of the controller to pry the two cases apart.

## Step 6



- Grasp the controller by the battery compartment and the headphone jack.
- Lift the battery compartment away from the headphone jack, separating the rear case from the front case and logic board.
- ☒ The battery contact springs are held in place by slots in the battery housing in the rear case. Be sure to realign them properly during reassembly.

## Step 7 — Vibration Motors



- Use the flat end of a spudger to remove the vibration motor cable, moving it upward from its socket on the logic board.
- Lift the vibration motor out of the front case.

## Step 8



- Remove the vibration motor from the other side of the controller using the same method previously described.
- ⓘ The **left motor** has significantly more counterweight than the right motor.

## Step 9 — Logic Board



- Lifting from the headphone jack and power plug, remove the logic board from the front case.

## Step 10 — Bottom Panel



- Lift the bumper panel off of the front case.

## Step 11




- Remove the rubber pad from the back of the D-pad.

## Step 12



- Remove the two 7.0 mm silver Phillips screws from the back of the D-pad.

## Step 13



- ① The D-pad is secured to its backing by two diagonal clips, shown in red.
- Use a pair of [tweezers](#) and squeeze the clips together to release the D-pad from its backing.

## Step 14



- Lift the D-pad backing out of its compartment on the front case.
- The D-pad remains below the front case.
- ⓘ The D-pad will fall once its backing is removed. Be sure to support it as you remove the backing.
- ☑ The backing is slotted to its compartment to ensure that it will always be aligned properly.

## Step 15



- Remove the rubber pad from the back of the input buttons.

## Step 16



- Using a pair of tweezers, remove the following buttons from the front panel:

- A Button
- B Button
- X Button
- Y Button
- Start Button
- Select Button
- Guide Button

## Step 17



- Using a pair of tweezers, remove the LED ring from the front panel.

## Step 18



- Insert a spudger between the lower panel and front case.
- Slide the spudger along the gap between the two case components.
- Lift the lower panel off of the front case.

---

To reassemble your device, follow these instructions in reverse order.