




Lenovo ThinkPad X1 Carbon 6th Gen Touchpad Replacement

In this guide, you will learn how to replace...

Written By: Michael Megna



INTRODUCTION

In this guide, you will learn how to replace the touchpad of a Lenovo ThinkPad X1 Carbon 6th Gen. This may be necessary if your touchpad is no longer working properly. If you are having issues with your touchpad, see our [troubleshooting guide](#). Before replacing the touchpad, try updating or reinstalling the drivers first. Be sure to power off your device and disconnect it from any power source before beginning.

TOOLS:

Spudger (1)
Phillips #0 Screwdriver (1)
iFixit Opening Tool (1)
Nylon Tipped Tweezers (1)

PARTS:

01LV566 - Lenovo Laptop Touchpad - Genuine (1)

Step 1 — Back Cover




- Use a Phillips #0 screwdriver to unscrew the five screws that secure the back cover to the laptop.
- ⓘ The screws do not completely come off from the back cover. Loosen until the screws are completely loose.

Step 2



- Use a Jimmy to lift the cover directly up off of the locating pins.
- ① Though a metal opening tool is shown in the image, we recommend using plastic opening tools to minimize any cosmetic damage.
- Remove the back cover.
- ① If you encounter resistance when lifting the cover, revisit the screws to see if any of them are still threaded on to the device.

Step 3 — Battery





- Use the Phillips #0 screwdriver to remove the four 5 mm screws that secure the battery to the laptop frame.

Step 4




- Take out the battery by lifting it from the bottom edge of the laptop, and then pulling away from the motherboard.

Step 5 — Fingerprint Scanner




- Use the Phillips #0 screwdriver to remove the 2mm screw that secures the cover of the fingerprint scanner.

Step 6





- Remove the cover by grabbing it and gently pulling up and to the left.

Step 7



- Use a nylon spudger to lift up the black bar that secures the cable.
- Disconnect the ribbon cable from the fingerprint scanner by pulling the cable directly out.



Step 8 — Touchpad



- Use a spudger to peel back the black adhesive pad.



⚠ Be gentle; the black adhesive pad is delicate and may rip.

Step 9





- Lift the lever that secures the cable.
 - Pull the cable out to disconnect the ribbon cable that connects to the touchpad.
- ① This is the same procedure for removing most of the ribbon cables.

Step 10



- Use a Phillips #00 screwdriver to remove the four 1mm screws that secure the touchpad to the laptop.

Step 11



- Once the screws are removed, the touchpad can be removed.
- ① The touchpad may even fall out once the screws are removed. Be sure to secure the touchpad before it falls out.

To reassemble your device, follow these instructions in reverse order.