



MacBook Pro 15" Unibody Mid 2009 Hard Drive Replacement

Written By: Andrew Bookholt



INTRODUCTION

Upgrade your hard drive for more storage space.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Spudger](#) (1)
- [T6 Torx Screwdriver](#) (1)
- [P6 Pentalobe Screwdriver 2009 MacBook Pro Battery](#) (1)



PARTS:

- [MacBook and MacBook Pro \(Non-Retina\) SSD Upgrade Bundle](#) (1)
 - [250 GB SSD](#) (1)
 - [500 GB SSD](#) (1)
 - [1 TB SSD](#) (1)
 - [500 GB SSD Hybrid 2.5" Hard Drive Upgrade Kit](#) (1)
This kit contains the part and all tools needed.
 - [1 TB SSD Hybrid 2.5" Hard Drive Upgrade Kit](#) (1)
This kit contains the drive and all tools needed.
 - [500 GB 5400 RPM 2.5" Hard Drive](#) (1)
 - [1 TB 5400 RPM 2.5" Hard Drive](#) (1)
 - [MacBook Pro 15" Unibody \(Mid 2009 to Mid 2012\) Hard Drive Bracket](#) (1)
 - [Universal Drive Adapter](#) (1)

Step 1 — Lower Case




- Remove the following ten screws securing the lower case to the upper case:
 - Seven 3 mm Phillips screws.
 - Three 13.5 mm Phillips screws.

Step 2



- Using both hands, lift the lower case near the vent to pop it off two clips securing it to the upper case.
- Remove the lower case and set it aside.

Step 3 — Battery




- Remove the two [5-Point Pentalobe](#) screws along the top edge of the battery.
- ⓘ You do not necessarily have to follow steps 3-6 to remove the battery in order to replace the hard drive. However it is recommended to remove all power sources from electronics before working on them.

Step 4



- Use the tip of a spudger to bend back the finger of the "Warning: Do not remove the battery" sticker while you remove third five-point Pentalobe screw hidden underneath.


Step 5



- Lift the battery by its plastic pull tab and slide it away from the long edge of the upper case.

⚠ Do not try to completely remove the battery just yet.

Step 6



- Tilt the battery back enough to access the battery cable connector.
- Pull the battery cable connector away from its socket on the logic board and remove the battery from the upper case.
- ✦ If you're installing a new battery, you should [calibrate](#) it after installation.

Step 7 — Hard Drive



- Remove the two Phillips screws securing the hard drive bracket to the upper case.
- ⓘ These screws are captive to the hard drive bracket.
- Lift the the retaining bracket out of the upper case.

Step 8




- Lift the hard drive by its pull tab and pull it out of the chassis, minding the cable attaching it to the computer.

Step 9



- Remove the hard drive cable by pulling the hard drive straight away from the connector. Keep the connector steady. If pulled by the connector, it can be pulled too far and accidentally tear the hard drive cable.

Step 10 — Hard Drive



- Remove two T6 Torx screws from each side of the hard drive (four screws total).
- ☑ You'll need to transfer these screws to your new hard drive if you're changing drives.
- ⓘ If you are installing a new hard drive, we have an [OS X install guide](#) to get you up and running.

To reassemble your device, follow these instructions in reverse order.