



Lenovo Yoga 2 13" Screen Replacement

This guide will explain how to safely remove...

Written By: Nichelle



INTRODUCTION

This guide will explain how to safely remove the screen from your Lenovo Yoga 2 13" laptop. It will provide a list of the tools needed as well as the easiest way to remove the screen without damaging it.


TOOLS:

[Jimmy](#) (1)
[Flathead 3/32" or 2.5 mm Screwdriver](#) (1)
[Small Phillips Screwdriver](#) (1)
[iFixit Opening Picks \(Set of 6\)](#) (1)

PARTS:

[90400287 - Lenovo Yoga 2 13" LCD](#) (1)
[90400288 - Lenovo Yoga 2 13" LCD HD](#) (1)

Step 1 — Screen




- Using an opening pick, remove one small black rectangle piece on each of the hinge corners to locate screws.
- Using a Phillips head screwdriver, carefully remove one 4.8 mm screw from each corner.

Step 2




- Using the Jimmy, remove the long centerpiece covering between the hinges.

Step 3



- Detach the screen from the front panel by sliding the screen up about 2mm. Do not pull too far, as there are still connected wires.

Step 4



- Locate the gold wire and follow it to two clips. Remove the clips and the clear tape securing the wire.
- Gently unsnap the wire from the hooks along the perimeter, and remove any tape along the wire.

Step 5



- Completely separate the screen from the laptop.
 - ☒ During reassembly, remember to set the screen about 2 mm beyond the lid top edge. Then, slide down to engage the hinges.

To reassemble your device, follow these instructions in reverse order.